


# **DDCS-Expert**

## Standalone Motion Controller Users Manual V1



This Manual based on:  
Software Version: 2020-09-28  
Hardware Version:2020-401-0

All copyrights reserved  
Shall not be reproduced without permission.

**深圳市众联拓数控科技有限公司**  
Shenzhen Digital Dream Numerical Technology Co., Ltd.

# Contents

1	DDCS-Expert Brief Introduction	3
1.1	Product Brief Introduction	3
1.2	DDCS-Expert Brief technical feature	4
1.3	Appearance, Structure and Size of Product	5
1.4	Explanation of Abbreviations	7
2	Controller Panel and Operation	8
3	Input and Output Ports	10
4	Wiring	15
4.1	Wiring Board Overview	15
4.2	Power Supply Input	18
4.3	Spindle Wiring	20
4.3.1	Analog Spindle	20
4.3.2	Servo Spindle (PLUSE/DIRECTION)	22
4.3.3	Multi-Speed Spindle	22
4.3.4	Relay Wiring	24
4.4	Stepper /Servo Driver Wiring	25
4.5	Limit, Home and Probe Inputs	27
4.6	External Buttons	29
4.7	MPG Wiring	29
4.8	Series Port Wiring	20
5	Software and Operation	33
5.1.1	The Main Page of the software	34
5.1.1.1	FRO	38
5.1.1.2	SRO	38
5.1.1.3	SJR/Jog Step	39
5.1.1.4	Feed Rate	41
5.1.1.5	Analog S/Servo S/Multi-Speed	43
5.1.2	Simulation	46
5.1.3	Probe	49
5.1.3.1	Floating Probe	49

5.1.3.2	Fixed Probe	51
5.1.4	Go work Zero	53
5.1.5	Go Home	54
5.1.6	Clear	57
5.1.7	Break Run (Breakpoint Resume)	58
5.1.8	Manual	60
5.1.9	Coord Set	62
5.1.9.1	Select Coord	63
5.1.9.2	Clear X / Y / Z / 4th / 5th A xis	64
5.1.9.3	Set Z Step	65
5.1.9.4	Deeper and Move up	65
5.1.10	MDI	66
5.1.11	Middle	69
5.1.11.1	Find Middle Point in X Axis	70
5.1.11.2	Find Middle Point in Y Axis	72
5.1.11.3	Find a middle point f or the Arc	74
5.1.12	Work Record	78
5.1.13	Sort Process	80
6	Program	82
7	Parameters	85
7.1	Parameters List and Details	85
7.2	Search the Parameters by the Number	100
7.3	Parameter Setting Backup	102
7.4	Parameters Restore	103
8	System Info	105
8.1	Registration	106
8.2	Password Setting	109
8.3	System Update (System Software Update)	111
8.4	System Set	114
8.4.1	System Time Setting	114
8.4.2	Set IP Address manually by Ethernet Cable	116
8.5	System BackUp	131
9	G Code and M Code	132

The copyright of this manual belongs to Shenzhen Digital Dream Numerical Technology Co., Ltd. (herein after referred as Digital Dream Company). This manual and any image, table, data or other information contained in this manual may not be reproduced, transferred, or translated without any prior written permission of Digital Dream Company.

The information contained in this manual is constantly being updated. You can login to the official website of Digital Dream Company [www.ddcnc.com](http://www.ddcnc.com) to download the latest PDF edition for free.

# 1 DDCS-Expert Brief Introduction

## 1.1 Product Brief Introduction

Thank you for your interest in our standalone motion controller and for taking the time to read this manual.

Digital Dream is a numerical control company specializing in the research, development and production of various CNC (Computer Numerical Control) systems since 2008. Digital Dream aims to combine high quality and high reliability with affordability.

The DDCS Expert is a 3~5 axes motion controller for open or close stepper and servo systems with 7/10.2 full color display screen. The highest output pulse per axis is 1MHz. The users can self-define the functional keys. This controller supports multiple spindle mode, support straight Tool Magazine, gantry type Magazine, disk type magazine. The Operation system interface even though very comprehensive, can be learned in very short time.

The DDCS Expert numerical control system adopts the ARM+FPGA design framework. ARM controls the human-computer interface and code analysis and the FPGA provides the underlying algorithms and creates the control pulse. This guarantees reliable control and easy operation. The internal operating system is Linux based.

The DDCS Expert can be used for many styles and types of CNC machines. Lathes, Routers, Pick&Place and Mills, lathe and cutters are just a few examples. The DDCS Expert operates as a Stand Alone system without the need of a computer. This guarantees high precision, accuracy and reliability.

## 1.2 DDCS-Expert Brief technical feature:

- 1) Max. 5 Axis; 1M Hz output frequency for each axis; 2-4 Axis linear interpolation, any 2 axis circular interpolation;
- 2) 7 inch full color display screen; resolution ratio: 1024\*600, 40 operation keys;
- 3) 24 photoelectric isolated digital inputs, 21 photoelectric isolated digital outputs;
- 4) Analog spindle control 0-10V spindle control, also support PWM Output;
- 5) Magazine type: Supports multiple spindle mode, support straight Tool Magazine, gantry type Magazine, disk type magazine;
- 6) Probe Mode: Support Floating Probe and Fixed Probe;
- 7) Backlash compensation methods: direction gap compensation, radius gap compensation, length compensation;
- 8) Interpolation Algorithm: S type, circular hard algorithm, circular soft algorithm;
- 9) Language: Chinese, English;
- 10) Software Alarms: Program Error, operation Error, overtravel Error, Driver Error and so on;
- 11) Network: Support file share and online machining the remote files by Ethernet;
- 12) Spindle control mode support Multi-speed (3 lines 8 kinds speed), 0-10V Analog output, and servo spindle output;
- 13) Compatible with standard G-code, support popular CAD/CAM software, such as ArtCam, MasterCam, ProE, JDSoft SurfMill, Aspire, Fusion 360 and so on;
- 14) The control system can preview the processing path before machining, and it makes the system more steady, working smoothly and precise;
- 15) Support high speed machining in continuous Polyline segment, system can choose a most efficient algorithm automatically from different kinds Polyline segment algorithm;
- 16) Support un-limited size file for machining;
- 17) Support Pause Breakpoint resume, "Power Cut" recovery, Start from the specific line;
- 18) Support time-lock function;
- 19) Support 4 kinds operation rights: visitor, operator, admin, super admin;
- 20) Support function of "Try cutting" (handwheel guiding) and "Single-stage processing mode" and so on;
- 21) Support the function of Back to original point
- 21) The Power Supply for the controller is 24VDC, minimum Current is 0.5A;
- 22) The Power Supply for IO Port is 24VDC, minimum current is 0.5A; By the IO power supply, system already supply the power to IO ports. So no need the external power supply.

### 1.3 Appearance, Structure and Size of Product

The DDCS-Expert is a small box that can fit in a window of a small control box or control cabinet. Four locking hooks fix this controller from the frame. The dimension you find in Figure 1-1 and Figure 1-2.

The front panel is 268mm\*172.5mm\*5.2mm;

The main body is 268mm\*172.5mm\*70mm;

To mount the unit in an equipment cabinet, cut the hole 258.4mm\*109mm




Figure 1-1 DDCS-Expert(DDCSE) Back view and dimensions




Figure 1-2 (DDCSE) Side view and dimensions

The front panel consists of 40 user keys and the 7 inch (1024\*600) LCD.



Figure 1-3 Front panel




Figure 1-4 Back Side of the controller

The only accessories is the USB extended cable.



Figure 1-5 USB extended cable

## 1.4 Explanation of Abbreviations

When operating the DDCS, the users will come across some English abbreviations. Here a list with explanations:

FRO: Feed Rate Override

SRO: Spindle Rate Override

SJR: Jog Speed Setting

F: Feed rate, unit is mm/min

S: Spindle Speed, unit rev/min.

X: The coordinate code of the X axis.

Y: The coordinate code of the Y axis.

Z: The coordinate code of the Z axis.

A: The coordinate code of the A axis

B: The coordinate code of the B axis

BUSY: The system is busy. You still can adjust FRO and SRO

READY: READY mode, any operation can be done

RESET: Reset mode, controller is in "OFF" mode, no operation can be performed

CONT: Continuous mode, each axis can be manually jogged with the arrow keys

Step :Manual Step Mode, each axis can be jogged in defined steps

MPG: MPG mode. Operate the machine with the MPG (Manual Pulse Generator)

BUSY: Run G code. Auto is showing when file is processing

## 1.5 Notes and Warnings



Keep away from exposure to moisture or water. This product contains sophisticated electronics and must not get wet.

Wiring warning: the IO input terminal of this controller supports equipment with source power (such as Inductive Proximity Switch ). When using this kind of equipment, pay attention to the polarity. Avoid the +terminal to be connect with GND. This controllers has analog output for spindle control (0-10V). Please avoid this terminal to ever connect with GND as damage to the controller may occur.



Operation warning. Please observe all security measures when operating the machine. The ESTOP must be connected and properly labelled. In case of a problem, press the E-stop at once to avoid damage to humans, animals and the equipment.



High voltage danger. The DDCS is connected to 24V DC. Obey and follow the electricity safety rules of your country when connecting this equipment.



## 2 Controller Panel and Operation























Figure 2-1 DDCS-Expert (DDCSE) Controller Panel

Keys Icon	Definition	Notes
	Return to previous menu	In the software, press the key to return to previous menu.
	Go to Next Page	In the software, press the key to the next page of the sub-menus.
	Sub-menu key F1~ F6	Sub-menu keys need to work according with the controller software.
	Extend function key K1~ K7	In the Para Page, the users can define K1-K7 Keys.
	Spindle manual start/close	Press this key to manually switch the spindle on or off. Can not be used if Reset is blinking and while processing an operation (Busy) When the LED lights up, then the spindle start.
	Try cut Enable/Disable	Press this key to Enable or Disable the Try-Cut (Handwheel guiding) function.
	Mode switch	When in READY, this key changes the Jog mode from Continuous to Step and MPG control.
	Start operation	After loading the G code file, please press this key to start the operation. In case of Pause Status, press this key to continue the processing operation.
	Pause operation	Press this key to Pause the operation.
	Reset and E-STOP	If Reset is blinking, press this key to activate the controller again. Press this key to stop the programming urgently.

Keys Icon	Definition	Notes
	1: Cursor moves quickly 2: Ratio/Values increase or decrease 3: Push to Enter	In the Monitor Page, by turning the knob, it can move among different column; after selecting the column, we can adjust the values fast and easily; In the Program page, by turning the knob, we can select files quickly and press it to confirm; In the Parm and IO page, it also have the same functions.
	1: Cursor moves Up 2: Parameter value increases 3: Highlight the Selections	In Monitor, the key can highlight the processing parameters FRO/SRO/SJR and so on; In Program/Param/IO page, it highlight the selections.
	1: Cursor moves Down 2: Parameter value decreases 3: Highlight the Selections	In Monitor, the key can highlight the processing parameters FRO/SRO/SJR and so on; Program/Param/IO page, it highlight the selections.
	1: Cursor moves Left 2: Moves through Para Kinds	In Param Page, the key moves among the Para Kinds; In IO page, It moves the cursor left.
	1: Cursor moves Right 2: Switch through Para Kinds	In Param Page, the key moves among the Para Kinds; In IO page, It moves the cursor right.
	1: BackSpace Key 2: Cancel or Delete Key	By it we can come back to the main page, cancel and delete the value input, cancel the current action and so on.
	1: Confirm and Enter key	In "CONT Mode", the X axis will Continuously move positive after pressing this key. In "STEP Mode" X will move positive in steps.
	1: X axis moves right; 2: Number "6".	In "CONT Mode", the X axis will Continuously move positive after pressing this key. In "STEP Mode" X will move positive in steps.
	1: X axis moves left; 2: Number "4".	In "CONT Mode", the X axis will Continuously move negative after pressing this key. In "STEP Mode" X will move negative in steps.
	1: Y axis moves forward; 2: Number "8".	In "CONT Mode", the Y axis will continuously move positive after pressing this key. In "STEP Mode" Y will move positive in steps.
	1: Y axis move backward; 2: Number "2".	In "CONT Mode", the Y axis will continuously move negative after pressing this key. In "STEP Mode" Y will move negative in steps.
	1: Z axis Up 2: Number "9".	In "CONT Mode", the Z axis will continuously move positive after pressing this key. In "STEP Mode" Z will move positive in steps.
	1: Z axis down 2: Number "1".	In "CONT Mode", the Z axis will continuously move negative after pressing this key. In "STEP Mode" Z will move negative in steps.
	1: The 4th Axis rotates in forward direction 2: Number "7".	In "CONT Mode", the 4th axis will continuously move positive after pressing this key. In "STEP Mode" it will move positive in steps.
	1: The 4th Axis rotates in inversion direction 2: Number "3".	In "CONT Mode", the 4th axis will continuously move negative after pressing this key. In "STEP Mode" it will move negative in steps.
	1: The 5th Axis in forward direction 2: The Symbol "-".	In "CONT Mode", the 5th axis will continuously move positive after pressing this key. In "STEP Mode" it will move positive in steps.
	1: The 5th Axis in inversion direction 2: The Symbol ".".	In "CONT Mode", the 5th axis will continuously move negative after pressing this key. In "STEP Mode" it will move negative in steps.
	1: High or Low Speed selection 2: Number "5".	When the LED lights up, it is in high-speed mode.
	1: Breakpoint resume active 2: Number "0".	When the LED lights up, the breakpoint resume is active.

### 3 Input and Out Ports

DDCS-Expert controller creates a self-defined IO ports method. According to the user's favorite, the users can define the input and output ports as which they want. In the IO page, the users can define the input port and output port, and also can inspect the input/output port and MPG status.

Power on the DDCS-Expert controller, system popup the main page, and press F4 Key to go to the IO Port Page:




Figure 3-1 Press F4 to IO Page

Page of the IO pop up as below. In the page, you can use the Up/Down arrow, Right/Left arrive and Knob to select and change the settings.




Figure 3-2 IO Page

## Column 1: The input and output port definitions:

Status	Port Name	Enable	Pin No.	Polarity
● or ●	X-axis servo alarm signal	X or √	NULL or IN01-IN24	N or p
	Y-axis servo alarm signal			
Green: Means the status is not active.	Z-axis servo alarm signal	X: Means the signal is disabled.	NULL: No definition.	N: Negative pole
	Spindle alarm signal			
	5th-axis servo alarm signal			
Red: Means the status is active.	Negative X-axis hard limit signal	√: Means the signal is enabled.	IN01-IN24: Input port 1 to Input port 24	P: Positive pole
	Negative Y-axis hard limit signal			
	Negative Z-axis hard limit signal			
	Negative 4th-axis hard limit signal			
	Negative 5th-axis hard limit signal			
	Positive X-axis hard limit signal			
	Positive Y-axis hard limit signal			
	Positive Z-axis hard limit signal			
	Positive 4th-axis hard limit signal			
	Positive 5th-axis hard limit signal			
	X-axis Zero Signal			
	Y-axis Zero Signal			
	Z-axis Zero Signal			
	4th-axis Zero Signal			
	5th-axis Zero Signal			
	Floating Probe signal			
	Fixed Probe signal			
	External key 1			
	External key 2			
	External key 3			
External key 4				
External key 5				
External key 6				
External Start				
External Pause				
External Estop				
Spindle Stop Signal (M300)				
Tool release input signal (M301)				
Tool lock input signal (M302)				
Tool open input signal (M303)				
Dust cover open/close input signal (M305/M306)				
Inverter Alarm input signal				
Customs alarm input signal 1				
Customs alarm input signal 2				
Customs alarm input signal 3				
Customs alarm input signal 4				
Customs alarm input signal 5				
Tool close input signal (M304)				

Status	Port Name	Enable	Pin No.	Polarity
● or ●	Spindle forward rotation control signal	X or √	NULL or OUT01-OUT21	N or p
	Spindle reverse rotation control signal			
Green: Means the status is not active.	Spindle section speed 1	X: Means the signal is disabled.	NULL: No definition.	N: Negative pole
	Spindle section speed 2			
	Spindle section speed 3			
Red: Means the status is active.	M8/M9 control signal	√: Means the signal is enabled.	OUT1-OUT24: Output port 1 to output 21	P: Positive pole
	M10/M11 control signal			
	System alarm signal			
	System Running signal			
	System Brake signal			
	System ready signal			
	Tool release/lock signal (M154/M155)			
	Tool launch/retract signal (M152/M153)			
	Front positioning/off signal (M156/M157)			
	Vacuum pump on/off output signal (M158/M159)			
	Dust cover open/close output signal (M150/M151)			
	Push cylinder open/close output signal (M160/M161)			
	Vacuum cleaner on/off output signal (M162/M163)			
	Left positioning on/off output signal (M164/M165)			
	Vacuum valve open/close output signal (M166/M167)			
Multi-process 1 Open/close output signal (M168/M169)				
Multi-process 2 Open/close output signal (M170/M171)				
Multi-process 3 Open/close output signal (M172/M173)				
Multi-process 4 Open/close output signal (M174/M175)				
Cooling 1 on/off output signal (M176/M177)				
Cooling 1 on/off output signal (M178/M179)				

**Important:**

In the controller default setting, we already define the Output port 21 as the “Spindle forward rotation control”. On the controller wiring board, we didn’t name it as “Out21”, we name it as “FRO”.




Figure 3-3 FOR Output Port

### Column 2 and Column 4:

Show the input ports or output ports are on the short-circuit or not.

If the little block becomes Red,the according port is on the short-circuit; if it' s still black,the according port is not on the short-circuit.

For example, we define the IN01 as the “X-axis Zero Signal” , and when the X axis touched the limited switch, it will show as below:

CONT	READY	/local/BMP1.bmp	IO	2020/01/22 03:37:34	Guest								
Stat	Port Name			Enable	Pin No.	Polarity							
●	positive X-axis hard limit signal			x	NULL	N							
●	positive Y-axis hard limit signal			x	NULL	N							
●	positive Z-axis hard limit signal			x	NULL	N							
●	positive 4th-axis hard limit signal			x	NULL	N							
●	positive 5th-axis hard limit signal			x	NULL	N							
●	X-axis zero signal			✓	IN01	N							
●	Y-axis zero signal			✓	IN02	N							
●	Z-axis zero signal			✓	IN03	N							
●	4th-axis zero signal			✓	IN04	N							
●	5th-axis zero signal			✓	IN05	N							
●	Floating Probe signal			x	NULL	N							
●	Fixed Probe signal			x	NULL	N							
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
	IN14	IN15	IN16	IN17	IN18	IN19	IN20	IN21	IN22	IN23	IN24		
MPG	X1	X10	X100	HX	HY	HZ	HA	HB		0		15	
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
	OUT14	OUT15	OUT16	OUT17	OUT18	OUT19	OUT20	OUT21					
▲	Out Open	Out Close					Change Polarity						

Figure 3-4 Input 01 is conducting with COM-

But,the status is active, doesn' t mean that the according signal is active. For example,we reverse the signal' s polarity, and moves the X axis away from the limit switch, the status light and IO block show as below: the X-axis zero signal is active,and IN01 Block is not on,because IN01 is not conducting with COM-.

CONT	READY	/local/BMP0.bmp	IO	2020/01/22 03:52:30	Super								
Stat	Port Name			Enable	Pin No.	Polarity							
●	positive X-axis hard limit signal			x	NULL	N							
●	positive Y-axis hard limit signal			x	NULL	N							
●	positive Z-axis hard limit signal			x	NULL	N							
●	positive 4th-axis hard limit signal			x	NULL	N							
●	positive 5th-axis hard limit signal			x	NULL	N							
●	X-axis zero signal			✓	IN01	P							
●	Y-axis zero signal			✓	IN02	N							
●	Z-axis zero signal			✓	IN03	N							
●	4th-axis zero signal			✓	IN04	N							
●	5th-axis zero signal			✓	IN05	N							
●	Floating Probe signal			x	NULL	N							
●	Fixed Probe signal			x	NULL	N							
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
	IN14	IN15	IN16	IN17	IN18	IN19	IN20	IN21	IN22	IN23	IN24		
MPG	X1	X10	X100	HX	HY	HZ	HA	HB		0		15	
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
	OUT14	OUT15	OUT16	OUT17	OUT18	OUT19	OUT20	OUT21					
▲	Out Open	Out Close					Change Polarity						

Figure 3-5 The status is active but IN01 is not ON

Here we move the X axis to touch the limit switch, but status light doesn't light up. So the Status shows the signal is active or not, the IN01-IN24 Block shows the port is conducting or not.

CONT	READY	/local/BMP0.bmp	IO	2020/01/22 03:52:25	Super								
Stat	Port Name				Enable	Pin No.	Polarity						
●	positive X-axis hard limit signal				x	NULL	N						
●	positive Y-axis hard limit signal				x	NULL	N						
●	positive Z-axis hard limit signal				x	NULL	N						
●	positive 4th-axis hard limit signal				x	NULL	N						
●	positive 5th-axis hard limit signal				x	NULL	N						
●	X-axis zero signal				✓	IN01	P						
●	Y-axis zero signal				✓	IN02	N						
●	Z-axis zero signal				✓	IN03	N						
●	4th-axis zero signal				✓	IN04	N						
●	5th-axis zero signal				✓	IN05	N						
●	Floating Probe signal				x	NULL	N						
●	Fixed Probe signal				x	NULL	N						
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
MPG	X1	X10	X100	HX	HY	HZ	HA	HB			0		15
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
▲	Out Open		Out Close		Change Polarity								

Figure 3-6 The Signal is not active but port in conducting

### Column 3:

Shows MPG setting status. As the following figure shows, the MPG current setting is X10, in Y axis; “-54” block is the calculator of wheels turning step; “0” block shows the the current cursor position.

MPG	READY	23232.txt	IO	2000/12/22 05:13:56	Guest								
Stat	Port Name				Enable	Pin No.	Polarity						
●	X-axis servo alarm signal				x	NULL	N						
●	Y-axis servo alarm signal				x	NULL	N						
●	Z-axis servo alarm signal				x	NULL	N						
●	Spindle alarm signal				x	NULL	N						
●	5th-axis servo alarm signal				x	NULL	N						
●	negative X-axis hard limit signal				x	NULL	N						
●	negative Y-axis hard limit signal				x	NULL	N						
●	negative Z-axis hard limit signal				x	NULL	N						
●	negative 4th-axis hard limit signal				x	NULL	N						
●	negative 5th-axis hard limit signal				x	NULL	N						
●	positive X-axis hard limit signal				x	NULL	N						
●	positive Y-axis hard limit signal				x	NULL	N						
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
MPG	X1	X10	X100	HX	HY	HZ	HA	HB			-54		0
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
▲	Out Open		Out Close		Change Polarity								

Figure 3-7 MPG Input Page

- Column 6: Open the output signal;
- Column 7: Close the output signal;
- Column 8: Change the Polarity to the reverse.

So now we finished the introduction on the IO port. Only when the users understand how to set the IO port and how to inspect the IO page, it will help us on Wiring.

# 4 Wiring

## 4.1 Wiring Board Overview

DDCS-Expert wiring board, there are about 7 parts as following:

- 1) System Power and IO Power supply input Ports;
- 2) Driver Signal output Ports;
- 3) Input and Output Ports;
- 4) Spindle Output Ports;
- 5) MPG Port;
- 6) Ethernet and USB interface;
- 7) HMI/RS232 interface.




Figure 4-1 Controller Wiring Ports Overview






Figure 4-2 Wiring diagram overview

Pin Mark	Name	Function	Parameter
PE	Protecting Earthing	Connect it to the Earth.	
24V	Power Supply Input for Controller System	Positive Side of Power Supply for Controller system	DC24V 3A
GND		<b>Ground</b>	
COM+	Power Supply Input for IO Ports	Positive Side of Power Supply for IO Port	
COM-		Negative side of Power Supply for IO Port	
XP+	X Axis Signal output	Pulse Signal Positive Output of the X Axis (5V)	Cable-driven Output; RS422 Standard; Max. Interpolation Pulse Frequency 1Mhz.
XP-		Pulse Signal Negative Output of the X Axis (5V)	
XD+		Direction Signal Positive Output of the X Axis (5V)	
XD-		Direction Signal Negative Output of the X Axis (5V)	
YD+	Y Axis Signal output	Direction Signal Positive Output of the Y Axis (5V)	
YD-		Direction Signal Negative Output of the Y Axis (5V)	
YP+		Pulse Signal Positive Output of the Y Axis (5V)	
YP-		Pulse Signal Negative Output of the Y Axis (5V)	
ZP+	Z Axis Signal output	Pulse Signal Positive Output of the Z Axis (5V)	
ZP-		Pulse Signal Negative Output of the Z Axis (5V)	
ZD+		Direction Signal Positive Output of the Z Axis (5V)	
ZD-		Direction Signal Negative Output of the Z Axis (5V)	
4P+	4th Axis Signal output	Pulse Signal Positive Output of the 4th Axis (5V)	
4P-		Pulse Signal Negative Output of the 4th Axis (5V)	
4D+		Direction Signal Positive Output of the 4th Axis (5V)	
4D-		Direction Signal Negative Output of the 4th Axis (5V)	
5P+	5th Axis Signal output	Pulse Signal Positive Output of the 5th Axis (5V)	
5P-		Pulse Signal Negative Output of the 5th Axis (5V)	
5D+		Direction Signal Positive Output of the 5th Axis (5V)	
5D-		Direction Signal Negative Output of the 5th Axis (5V)	
FOR	Spindle Start/Stop	Forward Rotation and Stop Output of spindle(OUT21)	The Max. capacity of the output ports is 30V,500mA.
COM-	Spindle Output COMMON	Cannot short connect with ACM	
VSO	Analog Output	Connect with Anaog input port of the inverter	0-10V spindle control
ACM	Analog Ground		
PWM	PWM Output	Connect with PEM input port of the inverter	Duty ratio
ACM	PWM Ground		
IN01 ... IN24	24 Input Ports	In the IO page,can configurate the ports as Servo Alarm ,limited,Zero,Probe,Start/Pause/Stop and so on.	Support Mechanical,photoelectric and promixity switch,24VDC; Type: NPN Active Level:0V
OUT01 ... OUT20	20 Output Ports	In the IO page,can configurate the ports as Lubrication,Cooling and so on.	Open collector output; Build-in Backward Diode;Driven current: 500mA; Driver voltage: 30V.

## 4.2 Power Supply Input

DDCS-Expert needs two power supplies, Main power is for controller system, IO Port power is for Input and Output and MPG ports. Both power supply is 24VDC, current is 3A. In the System Power input port, the marked 24V and GND is the main power input ports; In the IO power input ports, the COM+ and COM- is the power input ports for Input/Output Port and MPG. Please keep in mind, only when the two power supplies are connected correctly the controller can be work properly.

Many new users only give system power, then the limited switches, the relay, and MPG and spindle don't work at all, then please go to check if you also give power to IO ports.

IO power gives the power to all the IO ports, include the Limited switch, Relay, MPG, Etop and all other Input and output Ports, without it, spindle, MPG, Input and Output ports cannot work.

In order to avoid electrical noise it is highly recommended to use two separate 24V power supplies.

In order to avoid high-frequency electrical noise from power supply cable, it is highly recommended to install a noise filter at the power input to the switch power supply.




Figure 4-3 Power Supply Wiring Methods




Figure 4-4 How the IO Power gives power to the Input Ports




Figure 4-5 How the IO Power gives power to the Output Ports




Figure 4-6 The Power Supply Wiring Methods

## 4.3 Spindle Wiring

DDCS-Expert Support 3 kinds Spindle Mode: Analog Spindle / Servo Spindle (PUL+DIR) / Multi-Speed Spindle. In the Param Page, by #079, we can define the spindle mode.

### 4.3.1 Analog Spindle

In Analog Spindle, the speed controlling output terminal can output 0-10V. It can adjust the speed of the spindle motor by sending the voltage between 0 and 10V to the VFD according to the Spindle Speed Setting.

Controlling the speed of a spindle with a VFD (variable frequency drive) only needs the Start / Stop signal and the 0-10V signal to control the frequency.

FOR port is same wiring methods as the normal Output Ports.

FOR is for spindle forward rotation output or start / stop output;

Analog circuit is isolated with Power supply output, Never short connect the ACM and COM- (DCM);

If only need the Start and Stop command for the spindle, then just connect FOR output port of the controller with Start input port of the inverter.




Figure 4-7 Spindle Wiring Methods

Important:

The “VSO” and “PWM” only one port is available for one configuration. Use “VSO” port or “PWM” port, the two ports cannot be used at the same time.




Figure 4-8 Spindle Wiring Example

### 4.3.2 Servo Spindle (PLUSE/DIRECTION)

In Param Page #079, we set the “ Spindle interface type ” to “ Plu/dir ”, and In Param Page #080 define “ Spindle mapping axis ” to the axis as you need, this axis is defined to be a servo spindle.

### 4.3.3 Multi-Speed Spindle

There are 3 parameters related to the Multi-speed spindle:

#079 -- “ Spindle interface type ” ; Here we need to set it to “ Multi-speed ”;

#088 -- “ Multi-speed section counts ”; The section count value range is 2-8, the users can set 2-8 different spindle speed.

#082 -- “ Max. Spindle Speed ”.

For example, if the #088 set as 8, and the #082 is 24000, then if the current section is 2, the current spindle speed is 6000; if the current section is 3, the current spindle speed is 9000; if the current section is 4, the current spindle speed is 12000, ect...

There are 3 Output ports related to the Multi-speed spindle, the users need to define them to the according output ports.

Spindle section speed 1 = S1 ;

Spindle section speed 2 = S2 ;

Spindle section speed 3 = S3 ;




Figure 4-9 The relationship between the Multi-speed section and Spindle section output

Current Section	Output Status		
	S3	S2	S1
1	0	0	0
2	0	0	1
3	0	1	0
4	0	1	1
5	1	0	0
6	1	0	1
7	1	1	0
8	1	1	1

Note: 1 is output, 0 is no output.

Figure 4-10 The Relationship between the Current Section and Output Status

In the IO port Page, we already define the Out20 as “ Spindle section speed 1 ”,Out 19 as “ Spindle section speed 2 ”,Out18 as “ Spindle section speed 3 ”.The the wiring for the Multi-Speed Spindle as follwoing:




Figure 4-11 The Wiring for the Multi-Speed Spindle



### 4.3.4 Relay Wiring

By Configuration of more Spindle Output ports, the spindle control output terminal offers connections for Start / Stop of Cooling ( M8 / M9 ) and Start / Stop of Lubrication ( M10 / M11 ) and so on.

For example, it can be used for a Relay output port. Figure 4-12 shows the wiring methods.




Figure 4-12 The Relay Wiring

If Relay Power Supply is 24VDC:

DDCS Expert Input and Output are the user-defined IO ports, as our example here, we already set OUT10 as the “Cooling on/off” output port, and we already set the OUT01 as Vacuum valve on/off” output port.

If Relay Power Supply is not 24VDC:

The users need to use an external power supply, then please contact us to get the Schematics drawing.

## 4.4 Stepper /Servo Driver Wiring

The stepper / servo control output, we cite differential Pulse and Direction output method as Figure 1-12, Max. 1Mhz per axis. There is 3 or 4 or 5 axis for optional.

The Figure 1-12 we took X axis as the example, the Y, Z, A, B as the same wiring methods.

The Pulse and Direction signal output voltage is  $\pm 5V$ .




Figure 4-13 Pulse and direction signal wiring methods

Common anode wiring or common cathode wiring, is not DDCS-EXPERT wiring methods. The Figure 4-14 is the wrong wiring method.




Figure 4-14 Wrong wiring of pulse and direction

DDCSE Input and Output are the user-defined IO ports, In our example, we already set IN24 as the “5th axis servo alarm signal” input port.




Figure 4-15 Stepper/Servo driver connect with DDCS Expert

## 4.5 Limit, Home and Probe Inputs

DDCSE Input and Output are the user-defined IO ports, In our example, we already set IN12, IN11 and IN10 as the “ axis limit signal ” Input port, and we already set the IN09 as “ Probe ” output port.

Please note that the limit switch type should be NPN Normal Open, and the voltage range is 24VDC.




Figure 4-16 Proximity switch/Mecahnical switch and normal Probe wiring methods

Some users asked for the wiring methods for the probe with over-strock alarm, here we also set one sample for it.




Figure 4-17 The Probe sensor with over-strock alarm signal

In the example, we go to the IO port to sent the IN07 as the “Probe signal”, IN06 as “Negative Z- axis hard limit signal”:




Figure 4-18 The wiring methods of Probe sensor with over-stroked signal

## 4.6 External Buttons

DDCSE Input and Output are the user-defined IO ports, In our example, we already set IN23 as the “ External Start ” input port, IN22 as the “ External Pause ” input port, and IN21 as “ External Stop ” input Port.

Please choose the external buttons which is 24VDC Power supply input. Then no need an external power supply for them





Figure 4-19 The wiring methods of External buttons

## 4.7 MPG Wiring




Pin No.	Mark	Definition	Notes
1	+5V	Power Supply +	MPG Power supply input positive terminal
2	A+	Encoder A Phase +	MPG A phase differential input positive terminal
3	B+	Encoder B Phase +	MPG B differential input positive terminal
4	XIN	Select X Axis	Connect with GND,then X axis is selected
5	ZIN	Select Z Axis	Connect with GND,then Z axis is selected
6	X100	X100 Ratio	Connect with GND, then X100 ratio is selected
7	5	Select 5th Axis	Connect with GND,then 5th axis is selected
8	COM-	Input signal COMMON	The switch signal common trenimal.
9	GND	Ground	MPG power supply ground
10	A-	Encoder A Phase -	MPG A phase differential input negative terminal
11	B-	Encoder B Phase -	MPG B differential input negative terminal
12	YIN	Select Y Axis	Connect with GND,then Y axis is selected
13	4	Select 4th Axis	Connect with GND,then the 4th axis is selected
14	X10	X10 Ratio	Connect with GND, then X10 ratio is selected
15	EP	ESTOP Input	Connect with GND,then Estop is active

\*\*\* Never short connect the COM- and GND \*\*\* Figure 4-20 MPG wiring table

**IMPORTANT:**

- 1) All the input signal COMMON terminal is COM-, not GND; **Never short connect GND and COM-**;
- 2) The MPG need the power from IO power port ( COM+ / COM- ), or the MPG cannot work;
- 3) Because of the limit of the pins, if X10 and X100 is not selected, the system just select X1 by default.
- 4) With the MPG, and press the “Try Cut” key, the system can change to “Handwheel guiding” mode. Please Turn the Handwheel to counterclockwise direction, the Try Cut (Handwheel guiding) can be active.



DDCS-Expert Pin and Mark		MPG Function	MPG Pin and Mark	MPG Output Cable Color
1	+5V	Power Supply +	5V	RED
2	A+	A Phase +	A+	GREEN
3	B+	B Phase +	B+	PURPLE
4	XIN	X Axis	X	YELLOW
5	ZIN	Z Axis	Z	BROWN
6	X100	X100 Ratio	X100	ORANGE
7	5	5th Axis	5	PINK
8	COM-	MPG common COM-	COM	ORANGE/BLACK
9	GND	Ground	GND	BLACK
10	A-	B Phase -	B-	PURPLE/BLACK
11	B-	A Phase -	A-	WHITE
12	YIN	Y Axis	Y	YELLOW/BLACK
13	4	4th Axis	A	BROWN/BLACK
14	X10	X10 Ratio	X10	GREY/BLACK
15	EP	ESTOP	EP	BLUE

Figure 4-21 DDCS - Expert Wiring with DDMPG

In order to make the convenient for the users, we already solder the MPG cables to the PIN15 male interface plug, the users can just insert the MPG plug into the DDCS-Expert MPG interface.

After finished the wiring, we can check the MPG wiring is correct or not in the IO Page.

Look the figure 4-22 and 4-23, X100 and X block turns to red color, that means the X axis and X100 ratio is selected; -499 means the wheels was turned to counterclockwise direction; 922 means the wheels was turned to clockwise direction; -499 or 922 is not the actual distance, they are a measure of the turning speed . + or - shows the direction. So by this way, it is so easy to check the wiring of the MPG.

MPG	BUSY	/udisk-sda1/test.nc								IO	2020/01/29 00:00:08	Guest	
Stat	Port Name								Enable	Pin No.	Polarity		
●	X-axis servo alarm signal								x	NULL	N		
●	Y-axis servo alarm signal								x	NULL	N		
●	Z-axis servo alarm signal								x	NULL	N		
●	Spindle alarm signal								x	NULL	N		
●	5th-axis servo alarm signal								x	NULL	N		
●	negative X-axis hard limit signal								x	NULL	N		
●	negative Y-axis hard limit signal								x	NULL	N		
●	negative Z-axis hard limit signal								x	NULL	N		
●	negative 4th-axis hard limit signal								x	NULL	N		
●	negative 5th-axis hard limit signal								x	NULL	N		
●	positive X-axis hard limit signal								x	NULL	N		
●	positive Y-axis hard limit signal								x	NULL	N		
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
	IN14	IN15	IN16	IN17	IN18	IN19	IN20	IN21	IN22	IN23	IN24		
MPG	X1	X10	X100	HX	HY	HZ	HA	HB		-449		0	
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
	OUT14	OUT15	OUT16	OUT17	OUT18	OUT19	OUT20	OUT21					
▲	Out Open		Out Close					Change Polarity					

Figure 4-22 Turning wheels in CCW direction

MPG	BUSY	/udisk-sda1/test.nc								IO	2020/01/29 00:01:28	Guest	
Stat	Port Name								Enable	Pin No.	Polarity		
●	X-axis servo alarm signal								x	NULL	N		
●	Y-axis servo alarm signal								x	NULL	N		
●	Z-axis servo alarm signal								x	NULL	N		
●	Spindle alarm signal								x	NULL	N		
●	5th-axis servo alarm signal								x	NULL	N		
●	negative X-axis hard limit signal								x	NULL	N		
●	negative Y-axis hard limit signal								x	NULL	N		
●	negative Z-axis hard limit signal								x	NULL	N		
●	negative 4th-axis hard limit signal								x	NULL	N		
●	negative 5th-axis hard limit signal								x	NULL	N		
●	positive X-axis hard limit signal								x	NULL	N		
●	positive Y-axis hard limit signal								x	NULL	N		
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
	IN14	IN15	IN16	IN17	IN18	IN19	IN20	IN21	IN22	IN23	IN24		
MPG	X1	X10	X100	HX	HY	HZ	HA	HB		922		0	
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
	OUT14	OUT15	OUT16	OUT17	OUT18	OUT19	OUT20	OUT21					
▲	Out Open		Out Close					Change Polarity					

Figure 4-23 Turning wheels in CW direction

And in the Main Page, no matter the controller is in MPG or CONT or Step mode, just switch the MPG from Off to ON, the controller mode just turns to MPG mode;and also easily to see which axis the MPG is in, there will be a little mark on the related axis.





Figure 4-24 The MPG channel is on X axis


Note: If you want to use the single-terminal MPG (there is no A-B-MPG), please refer to Figure 4-25 for reference. As for the unlisted MPG, please take the differential MPG wiring mode.

DDCS Wiring Pin Mark	MPG Pin Mark and Color	
A+	A+	Green
A-	0V	Black
B+	B+	White
B-	0V	Black

Figure 4-25 DDCS Expert Wiring with Single-terminal MPG

## 4.7 Series Port Wiring

Series Port is for Modbus extension, it helps to extend with IO card, or the communication with PLC. If some users need it please contact factory and we will guide you for it.



Pin No.	Mark	Definition	Notes
1			
2	RXD1	Serial port 1 Receiver	
3	TXD1	Serial port 1 Sender	
4			
5	GND1	Serial port 1 Ground	
6			
7	RXD2	Serial port 2 Receiver	Serial port level is 232
8	TXD2	Serial port 2 Sender	Serial port level is 232
9	GND2	Serial port 2 Ground	

Figure 4-26 Series Ports wiring

# 5 Software and Operation

## Software Structure Part 1




Figure 5-1 Software Struction Part 1

# Software Structure Part 2




Figure 5-2 Software Struction Part 2

## 5.1.1 The Main Page of the software




Figure 5-3 Main Page of Monitor

The Figure 5-3 shows the Main Page of the DDCS Expert. It is divided into status column, coordinate display column, basic parameter column, and notification column. In total, it is divided into 19 sections in detail. Here the detailed description of the 19 sections :

#### 1、XYZAB Coordinate

This column shows the Machine coordinate and Current coordinate value of XYZAB axis. The display range is -99999.999 ~ +99999.999 in mm;

#### 2、Status

When the controller runs the G code file, it will show the current operation line and operation status.

#### 3、Feed status

This window shows the feed status of CONT.

AUTO: displayed while processing and executing the G code file

CONT: indicates Jog CONTINUOUS. You can Jog manually with the “-” or “+” keys of X Y Z and A and B.

STEP: Indicates STEP Jog mode. You can Jog manually in a defined distance with the “-” or “+” keys of X Y Z and A and B.

MPG: Only when shift to MPG mode, you can operate MPG on the controller.

#### 4、Operating Status

This column shows the operating state. The status and implications can be displayed as follows:

Busy: Operation is running

Reset: Reset flashing = controller not active. To activate the controller click Reset

READY: Ready state. Controller is ready and all operations can be performed

#### 5、Processing file

This column shows the name of the processing file and file path.

#### 6、Software Interface

This column shows the current software interface.

#### 7、Date and working time

This column shows the date and working time. The Date can be reset.

## 8、 User ' s rights

This controller Support 4 kinds operation rights: visitor, operator, admin, super admin.T his column shows the current rights.


## 9、 FRO

FRO controls the Feed Speed. Click FRO till FRO is highlighted. Use rotary button ( knob ) or Up / Down keys to adjust the Feed Speed in 1% increments, the range is 0% - 120%.

## 10、 SRO

SRO controls the Spindle Speed. Click FRO till SRO is highlighted, use rotary button(knob) or Up / Down keys adjust the Spindle Speed in 1% increments, the range is 0% - 150%.

## 11、 SJR / Jog Step

Press the  Key, the feed status shift among in CONT, STEP and MPG.

When the controller mode is CONT and MPG, it will show the SJR.

SJR controls the jogging of the machine. Turnning the rotary button (knob) till SJR is highlighted. Turnning rotary button (knob) or Up / Down keys to adjust the speed in 1% increments. The range is 0% - 120%. Press knob to enter the setting.

When in Step Mode, Pressing the rotary button (knob) or keys to change between the 4 distances 0.001 / 0.01 / 0.1 / 1 or define any distance.

When in MPG mode you can use the MPG to jog the machine

High/Low Speed: Manually speed

## 12、 Feed speed

F stands for Feed Speed. Turnning the rotary button or clicking up or down keys till F is highlighted, click button or Enter to modify and edit the value you want.

Here you can ignore the F value, then the system will use the F value from Gcode file, and also you can define a default F value. When the color the number is blue, then the system uses the default value, if the color is white, the system uses F speed from G-cdode file.

## 13、 Speed of spindle

Anolog S stands for Spindle Speed. Turnning the rotary button or clicking up or down keys till Analog S is highlighted, click button or Enter to modify and edit the value you want.

Here you can Ignore the S value, then the system will use the S value from Gcode file, and also you can define a defalt S value.

When the color the number is blue, then the system uses the default value,if the color is white, the system uses S speed from G-cdode file.

#### 14、Cur Tool :

This column display the current Tool No.

#### 15、 Total No.

Total Machinning No.

#### 16、 Cur No.

Current Machinning No.

When the Gcode file changed,t he number will be cleared to 0.

When excute M47 or M30, the counter will add 1, the working time cleared to 0; When M47 reached to the cycle times, the system pauses,and the number cleared to 0.

#### 17、 Cycle Times

Set a limited number of cycle times.

When system excute M47 from cycle Gcode file,and M47 excuting time reaches to cycle times which you set, system just pause itself, and clear current machinning No.

#### 18.Work Time

The working time for the current G-code file.




When restart the program,it will start to count.

#### 19. G49 H 0

The compensation setting.

### 5.1.1.1 FRO

FRO: Feed Rate Override.

In the Main Page, By the Rotary button (Knob)  or the  and  keys, we can shift among the different columns. We move the cursor, select FRO and enter, the percent number becomes blue, then we can use the knob or the Up / Down keys to edit the numbers. The percent number increase or decrease in 1%, range is 0% - 120%.

After the setting done, don't forget to press Enter to active the FRO.






FRO	98%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	7
Cur No.	0
Cycle Times	0
Work Time	00:00:00

Figure 5-4 When the percent number is Blue,we can edit FRO

### 5.1.1.2 SRO

SRO: Spindle Rate Override

In the Main Page, By the Rotary button(Knob)  or the  and  keys, we can shift among the different columns. We move the cursor, select SRO and enter, the percent number becomes blue, then we can use the knob or the Up/Down keys to edit the numbers. The percent number increase or decrease in 1%, range is 0% - 150%.




After the setting done, don't forget to press Enter to active the SRO.

FRO	98%
SRO	133%
Jog step	Low 0.001
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	7
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-5 When the percent number is Blue,we can edit SRO

### 5.1.1.3 SJR/Jog Step

When the controller mode is CONT or MPG, it is “ SJR ”; When the controller mode is STEP,it is “ Jog Step ”.


When in the CONT or MPG mode, By the Rotary button(Knob)  or the  and  keys, we can shift among the different columns. We move the cursor, select SJR and enter, the percent number becomes blue, then we can use the knob or the Up / Down keys to edit the numbers. The percent number increase or decrease in 1%,range is 0% - 120%.

After the setting done, don’ t forget to press Enter to active the SJR.

FRO	98%
SRO	137%
SJR	Low 118%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	7
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-6 When the percent number is Blue,we can edit SJR



Now we Press  key and shift the mode to STEP.

We press Enter and there a pull-down menu pop out. Now We have 5 choice: 0.001mm, 0.01mm, 0.1mm, 1mm and “ INC Distance ”. INC Distance means the users can define the distance at any value. We move the cursor to “ INC Distance ”, Press Enter and input 50, Enter, then a 50mm Step distance is active.



Figure 5-7 In Jog Step Mode



Figure 5-8 Define Distance






Figure 5-9 Input Number



Figure 5-20 new distance active

### 5.1.1.4 Feed Rate

In the “ Feed Rate ” column, we can define the default feeding rate, we can define the current working feedrate is F command from G-code or the feedrate value we set.

By the Rotary button(Knob)  or the  and  keys, we can shift among the different columns to “ Feed Rate ”. We press the Enter button, a small window pop up from the bottom. The “ Ignore F Yes ”, means Ignore the F command from the G-code, then the system will process by the F command we set here; The “ Ignore F No ” means the system ignore the Feed rate we set, control system will process by the F command from G-code file.

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-21 Shift to FeedRate Column

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Ignore F Yes	
Set default F	

Figure 5-22 Ignore F from G-code file

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-23 FeedRate value is active

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Ignore F NO	
Set default F	

Figure 5-24 Ignore FeedRate Value

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-25 F command from G-code file is active

And we can define the FeedRate Value by the pressing enter on “ Set Default F ”. We can write in numbers and press Enter again. Then the Feedrate value is done.



Figure 5-26 Set the Default Feed Rate



Figure 5-27 Write in the Value



Figure 5-28 The new Feed Rate Value already set

### 5.1.1.5 Analog S/Servo S/Multi-Speed

Because DDCS-Expert Controller has three kind Spindle Mode:

- 1) Analog: When the controller control the spindle speed by the analog 0-10V voltage output;
- 2) Plu/Dir: When define the spindle mode as the Servo Spindle;
- 3) Multi-Speed ( Multi Spindle Speed ): When the controller control the spindle speed by 3 input ports, this is Multi spindle speed control.

Go to the Param Page and find the #79 parameter,press Enter,there are 3 options.Each option decide different spindle Mode:

STEP	READY	/udisk-sca1/test.nc	Param	2020/01/27 06:47:12	Super
<b>Param List:</b>					
	No.	Note	Value		
Machine	0230	Execute action after Finished	No action		
Manual	0282	G00 ACC	2000.000		
----- Spindle -----					
Process	0079	Spindle interface type	Analog		
Spindle	0080	Spindle mapping axis	Analog		
IO	0081	Spindle start delay	Plu/dir		
	0082	Maximum spindle speed	Multi-speed		
Home	0083	Ignore the S command			
Probe	0084	Stop spindle when program is paused?			
	0085	Default spindle speed			
Hard Limit	0088	Multi-speed section counts	3		
Software limit	0089	Spindle stop delay	0.000		
MPG	---	IO	-----		
Backlash	0092	Duration of M8/M9 commands	2.000		
Tools	Range:	[0~2]	Active:	Immediately	User: Operator
System	Details:	Spindle interface type.			
▲ Param List    Search    Param Backup    Param Restore					

Figure 5-29 3 different spindle modes

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 4000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-30 Spindle in Analog Mode

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 4000
Servo S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-31 Spindle in Pul/Dir Mode

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 4000
Mult S	0-1 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-32 Spindle in Multi-Speed Mode

Here we only take the example of “Analog S” when the spindle mode is in Analog, to set the example:

By the Rotary button(Knob)  or the  and  keys, we can shift among the different

columns to “Analog S”. We press the Enter button, a small window pop up from the bottom. The “Ignore S Yes”, means Ignore the S command from the G-code, then the system will process by the S command we set here; The “Ignore S No” means the system ignore the Analog Spindle speed we set, control system will process by the S command from G-code file.

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-33 Shift to Analog S Column

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Ignore S Yes	
Set default S	

Figure 5-34 Ignore S from G-code file

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-35 Analog S value is active

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Ignore S NO	
Set default S	

Figure 5-36 Ignore Analog S Value

FRO	100%
SRO	100%
SJR	Low 100%
Feed Rate	0 3000
Analog S	0 24000
Cur Tool	T1
Total No.	0
Cur No.	0
Cycle Times	0
Work Time	00:00:00
G49 H 0	

Figure 5-37 S command from G-code file is active

And we can define the Analog Spindle Speed Value by the pressing enter on “ Set Default S ”. We can write in numbers and press Enter again. Then the Analog Spindle Speed setting is done.

When the spindle mode is in other two kinds mode,the operation is the same.



Figure 5-38 Set the Default Spindle Speed




Figure 5-39 Write in the Value



Figure 5-40 The new Spindle speed setting is done

## 5.1.2 Simulation

There are many Parameters related to the Simulation function:

Param #	Definition	Remark	Range
#244	Enable realtime toolpath	When processing a file,active realtime toolpath or not	Yes/No
#245	Toolpath mode	The Toolpath display modes	Statue/Line/3D
#261	X-axis rotation angle in 3D toolpath mode	Can set a angle to simulate Based on X axis	-180~180
#262	Y-axis rotation angle in 3D toolpath mode	Can set a angle to simulate Based on Y axis	-180~180
#263	Z-axis rotation angle in 3D toolpath mode	Can set a angle to simulate Based on Z axis	-180~180

In order to make the Simulation function active, we must set #244 to “Yes”;

And if the setting of #245 is “Line”, the system response can be quicker than Statue and 3D.

In the Monitor Page and Press F1, go to First Sub-Page of Monitor :




Figure 5-41 In the First Sub-page of Monitor and press F1 to go to the Simulation Page



Figure 5-42 Simulation Page

Press Start Key and the system start to simulate the G-code file :



Figure 5-43 Simulate a G-code file

Important:

- 1) Some users want that the system simulate the G-code file, but system does not send any signals. Then we need to go to Program file, select the file and simulate.
- 2) If it's first time the controller simulate the G-code file, the screen may not match well with the toolpath screen. But after one time simulation, the system can match the file well with the screen.




Figure 5-44 System is in Simulation




Figure 5-45 System is in Simulation






Figure 5-46 System is in Simulation




Figure 5-47 System is in Simulation




Figure 5-48 Simulation finished

## 5.1.3 Probe

The DDCS Expert has two kinds of the Probe mode: Floating Probe and Fix Probe. Firstly we must configurate right input ports to Flloating probe and fix probe in IO page, wire the ports correctly, as the Chapter 4.5 introduced.

CONT	READY	/udisk-scb1/5 axis testing.NC	Monitor	2020/10/04 15:52:07	Super
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕ X	5.000	0.000	SRO	100%	
⊕ Y	5.000	0.000	SJR	Low	100%
⊕ Z	-5.000	0.000	Feed Rate	0	99999
⊕ A	5.000	0.000	Analog S	0	24000
⊕ C	40.000	0.000	Cur Tool	T1	
Coord:	G54	Fixed Probe X:	5.720		
Cur Tool:	T1	Fixed Probe Y:	-58.053		
THK Of Probe:	10.000	Fixed Probe Z:	-38.677		
1:Before operate [Floating Probe].Pls move tool above the block and set Param 129;				Total No.	4
2:[Fixed Probe]Input the cutter No.,record the offset of Z axis after tool change;				Cur No.	0
3:[Mult Probe] Probe several tools at one time.select the Tools and press [Mult Probe].				Cycle Times	0
				Work Time	00:01:38
				G49 H 0	
▲ Floating Probe		Fixed Probe	Mult Probe	XY Teach	Z Teach

Figure 5-49 Probe Page

### 5.1.3.1 Floating Probe

There are many Parameters related to the Floating Probe:

Param #	Definition	Remark
#128	Is the Floating tool set valid?	Enable or Disable the Floating Probe
#129	Floating tool set thickness	Before floating probe,we need to measure out the sensor's thickness and set the #129.
#131	Probing cycle count	The probe times.When the user active the Probe,the system can probe 1 - 5 times as what the users set. At last system calculate an average value.
#132	Initial speed of Probing	The initial down speed of the Z axis after starting the tool setting.
#140	Retraction distance after the end of probe	This parameter is relative.
#63	G00 speed	Here the G00 is the probe speed.

Step 1: Firstly we must configurate the IO port,and wire the cables properly;

Step 2: We set the #128 to Yes,and we measure out the Tool sensor's thickness and set #129, and other parameters above;

Now we start to floating probe.

Firstly we must move the tool above the sensor manually.

We press F1 Key to active the floating probe, the system pops up a window to ask if the tool is just above the sensor,we press Enter the cutter start to probe down. It will probe the times we set, and calculate an average value, then the cutter retract a distance.Then the Floating probe finished.




Figure 5-50 Floating Probe




Figure 5-51 Star to Floating Probe




Figure 5-52 Floating Probe Finished

### 5.1.3.2 Fixed Probe

There are many Parameters related to the Fixed Probe:

	Definition	Remark	Range
#130	Is the fixed tool set valid?	Enable or Disable the Floating Probe	Yes/No
#131	Probing cycle count	The probe times. When the user active the Probe, the system can probe 1 - 5 times as what the users set. At last system calculate an average value.	1-5
#132	Initial speed of Probing	The initial down speed of the Z axis after starting the tool setting.	99 - 99999mm
#135	Fixed probe X mach position	The initial Position of X axis in Mach coordinate	-9999 ~ 9999mm
#136	Fixed probe Y mach position	The initial Position of Y axis in Mach coordinate	-9999 ~ 9999mm
#137	Fixed probe Z mach position	The initial Position of Z axis in Mach coordinate	-9999 ~ 9999mm
#138	Fixed probe 4th mach position	The initial Position of 4th axis in Mach coordinate	-9999 ~ 9999mm
#139	Fixed probe 5th mach position	The initial Position of 5th axis in Mach coordinate	-9999 ~ 9999mm
#140	Retraction distance after the end of probe	This parameter is relative.	0 - 999 mm
#63	G00 speed	Here the G00 is the probe speed.	99 - 99999

Step 1: Firstly we must configurate the IO port, and wire the cables properly;

Step 2: We set the #130 to Yes;

Step 3: Set the parameter #135 / 136 / 137 / 138 / 139 to find an initial position of probe tool;

Step 4: And set other parameters according to your request above;

Now we start to Fixed probe.

We press F3 Key to active the fixed probe, the system pops up a window to ask you to type in right Tool Number, we press Enter, the system start to Fix probe.




Figure 5-53 Fixed Probe




Figure 5-54 Type In the tool number and Enter

The X / Y / Z / 4th / 5th start to move to the initial position in Mach coordinate. After arriving to that position, it starts to probe down. It will probe the times as we set, and calculate an average value, and the cutter retracts a distance. Then the fixed probe is finished.




Figure 5-55 Fixed Probe Finished

The probe sequence of each axis is Z axis -- X axis -- Y axis -- 4th axis -- 5th axis.

## 5.1.4 Go work Zero

In the Monitor Page, Press F3 to go to “Go work Zero ” Page.




Figure 5-56 Go work Zero Page

Here the users can choose single axis go to zero, or can choose the All axis go to zero. In our example here we press F6 to “All go Zero ”.




Figure 5-57 Sub-page of Go Work Zero

CONT	READY	5 axis testing,NC	Monitor	2020/01/25 19:14:20	Guest
<b>G54</b>	<b>Mach</b>	<b>Abs</b>	FRO 100%		
X	0.000	0.000	SRO 100%		
Y	0.000	0.000	SJR Low 100%		
Z	5.000	5.000	Feed Rate 0.9999		
A	0.000	0.000	Mult 5 0-1 24000		
C	39.934	-0.066	Cur Tool T1		
			Total No. 7		
			Cur No. 2		
			Cycle Times 0		
			Work Time 00:00:00		
			G49 H 0		
▲	X Go Zero	Y Go Zero	Z Go Zero	4th Go Zero	5th Go Zero All Go Zero

Figure 5-58 All axis Go Zero

## 5.1.5 Go Home

Firstly no forget to go to IO page to configurate right ports for the X / Y / Z / 4th / 5th axis, and wire them correctly. Then we can start to Home.

There are many Parameters related to the Home function, we need to understand them and try to set each parameters correctly for our own usage.

Param #	Definition	Remark	Range
#100	Home mode	There are two mode of Home Mode, Here we only introduce Swtich Mode. If the users need Absolute mode, please contact our engineer to configurate.	Switch/Absolute
#106	Homing cycle count	Detection Times of Home action	1~5
#107	X-axis homing speed	X-axis initial speed when Home	99~99999 mm/min
#108	Y-axis homing speed	Y-axis initial speed when Home	99~99999 mm/min
#109	Z-axis homing speed	Z-axis initial speed when Home	99~99999 mm/min
#110	4th-axis homing speed	4th-axis initial speed when Home	99~99999 mm/min
#111	5th-axis homing speed	5th-axis initial speed when Home	99~99999 mm/min
#112	X-axis homing direction	The movement direction when Home of X-axis	Negative/Positive
#113	Y-axis homing direction	The movement direction when Home of Y-axis	Negative/Positive
#114	Z-axis homing direction	The movement direction when Home of Z-axis	Negative/Positive
#115	4th-axis homing direction	The movement direction when Home of 4th-axis	Negative/Positive
#116	5th-axis homing direction	The movement direction when Home of 5th-axis	Negative/Positive
#122	Mach position after X go home	X / Y / Z / 4th / 5th-axis Position in Mach Coordinate after Home. After all axis finished Homing,they will move to the according position we set here. The values are in Mach coordinate.	-999~999mm
#123	Mach position after Y go home		
#124	Mach position after Z go home		
#125	Mach position after 4th go home		
#126	Mach position after 5th go home		
#127	Home after booting	Whether pop-up a dialog box to ask if Go Home when Power On the Controller.	Yes/No
#235	X-axis Mach zero offset	We can reduce the error made by machine struction or any other factors by setting the offset for each axis.	-999~999mm
#236	Y-axis Mach zero offset		
#237	Z-axis Mach zero offset		
#238	4th-axis Mach zero offset		
#239	5th-axis Mach zero offset		




Figure 5-59 In Monitor Page Press F4 to “Go Home”

Here we can choose the single axis to Home, or we can All axis go home. In our example here, we choose the “All Go Home” by F6.




Figure 5-60 All go Home by F6



Figure 5-61 “All Go Home” Finished





Figure 5-62 Home Finished Symbol

As figure 5-20 showed, when the system finished Homing, that little symbol will appear on the related axis.

If the users only Home X axis, then only X axis has that symbol; If the users home all axis, all axis have that symbol. By the symbol, the users easily knows the machine was home or not.

So now we can see that our Homing action finished. Now the current position of each axis are not zero but like the figure 5-63. Because we already set the Parameters as below:

CONT	READY	5 axis testing.NC	Param	2020/01/25 21:05:40	Super
<b>Param List</b>					
		No.	Note	Value	
Machine		0114	Z-axis homing direction	Positive	
Manual		0115	4th-axis homing direction	Negative	
		0116	5th-axis homing direction	Negative	
Process		0122	Mach position after X go home	10.000	
Spindle		0123	Mach position after Y go home	10.000	
		0124	Mach position after Z go home	5.000	
IO		0125	Mach position after 4th go home	20.000	
Home		0126	Mach position after 5th go home	42.000	
Probe		0127	Home after booting	Yes	
		0235	X-axis Mach zero offset	0.000	
Hard Limit		0236	Y-axis Mach zero offset	0.000	
Software limit		0237	Z-axis Mach zero offset	0.000	
		0238	4th-axis Mach zero offset	0.000	
MFG		0239	5th-axis Mach zero offset	0.000	
Backlash					
Tools		Range:	[-999.000 -999.000] mm	Active:	Immediately
System		Details:	Mach position:	User:	Operator
<input type="button" value="Param List"/> <input type="button" value="Search"/> <input type="button" value="Param Backup"/> <input type="button" value="Param Restore"/>					

Figure 5-63 Mach Position after Home

We already set the Mach position after Homing. So when the system finished Homing, it will continue to move to the position which we set, this is the same function of Back distance after Home from DDCS V3.1.

We have a parameter also need to be noted also: #106 Homing cycle count, it is the Home times for each axis. For example, if we set 2 times, the each axis will go to the limited switch to be detected by two times.

Everytime we power on the controller DDCS-Expert, the system will pop-up a diagram as Figure 5-64, that is because of #127 "Home after booting". If we don't need it, we just disable it.



Figure 5-64 System ask If go to Home when Power on

The Home sequence is Z Axis -- X axis -- Y axis -- 4th axis -- 5th axis.

## 5.1.6 Clear

In the Monitor Page, Press F5 to go to “Clear” Page.




Figure 5-65 Go to “Clear” Page

Here the users can choose single axis go CLEAR, or can choose the All axis CLEAR. In our example here we press F6 to “Clear All”.




Figure 5-66 Sub-page of CLEAR



Figure 5-67 Clear All axis

### 5.1.7 Break Run (Breakpoint Resume)

In the Monitor Page and we Press F6 to enter into the “Break Run” page:



Figure 5-68 “Break Run” Page

As for the breakpoint resume function, we have 3 kinds breakpoint resume:

- 1) Start Line: Start from a specific line; the line number range from 1 - 10,000,000 lines;
- 2) Power Resume: Power Cut off recovery. When the power cut off, the system can remember the line when power cut off, and create a breakpoint.
- 3) Pause Resume: When pause the processing, the system remember the line when pause, and create a breakpoint.

In the Sub-page of “ Break Run ”, we press F1, the system will pop up a window to ask the user to input the start line no. We write in numbers and press enter, system will start to work from this specific line.




Figure 5-72 Start from a specific line



Figure 5-73 Input the line number

After power cut off or Pause, the controller can create a breakpoint number:



Figure 5-74 Breakpoint Line No.

If it is Power breakpoint, press F2, the system can power cut off recovery;  
 If it is Pause Resume, Press F3, the system will Pause breakpoint resume.

## 5.1.8 Manual

In the Monitor Page and we press  key to go to the second page of Monitor.




Figure 5-75 Go to second page of Monitor

Then we press F1 key to go to “Manual” Page.






Figure 5-76 Press F1 key to Manual Page



Figure 5-77 Manual Page

In Manual page, we can operate some simple functions as: Home, Clear and Zero; We can check the input ports status, to check it is conducting or not. And there is 14 virtual keys, by which, the users can define them as what they want.

By the Rotary button (Knob)  or the  and  keys, we can shift among the different blocks.

CONT	READY	Saxis testing.NC	Monitor			2020/01/26 00:41:54	Guest
G54	Mach	Abs	Go Home	Clear All	Go Zero	FRO	100%
X	10.000	0.000	X Home	X Clear	X Go Zero	SRO	100%
Y	10.000	0.000	Y Home	Y Clear	Y Go Zero	SJR	Low 100%
Z	5.000	0.000	Z Home	Z Clear	Z Go Zero	Feed Rate	0 99999
A	20.000	20.000	4th Home	4th Clear	4th Go Zero	Mult S	0-1 24000
C	42.000	42.000	5th Home	5th Clear	5th Go Zero	Cur Tool	T1
EXT KEY			IN			Total No.	7
FUNC K01	FUNC K08		IN01	IN09	IN17	Cur No.	0
FUNC K02	FUNC K09		IN02	IN10	IN18	Cycle Times	0
FUNC K03	FUNC K10		IN03	IN11	IN19	Work Time	00:00:12
FUNC K04	FUNC K11		IN04	IN12	IN20	G49 H 0	
FUNC K05	FUNC K12		IN05	IN13	IN21		
FUNC K06	FUNC K13		IN06	IN14	IN22		
FUNC K07	FUNC K14		IN07	IN15	IN23		
			IN08	IN16	IN24		

Figure 5-78 Here we can operate these functions

CONT	READY	Saxis testing.NC	Monitor			2020/01/26 00:41:50	Guest
G54	Mach	Abs	Go Home	Clear All	Go Zero	FRO	100%
X	10.000	0.000	X Home	X Clear	X Go Zero	SRO	100%
Y	10.000	0.000	Y Home	Y Clear	Y Go Zero	SJR	Low 100%
Z	5.000	0.000	Z Home	Z Clear	Z Go Zero	Feed Rate	0 99999
A	20.000	20.000	4th Home	4th Clear	4th Go Zero	Mult S	0-1 24000
C	42.000	42.000	5th Home	5th Clear	5th Go Zero	Cur Tool	T1
EXT KEY			IN			Total No.	7
FUNC K01	FUNC K08		IN01	IN09	IN17	Cur No.	0
FUNC K02	FUNC K09		IN02	IN10	IN18	Cycle Times	0
FUNC K03	FUNC K10		IN03	IN11	IN19	Work Time	00:00:12
FUNC K04	FUNC K11		IN04	IN12	IN20	G49 H 0	
FUNC K05	FUNC K12		IN05	IN13	IN21		
FUNC K06	FUNC K13		IN06	IN14	IN22		
FUNC K07	FUNC K14		IN07	IN15	IN23		
			IN08	IN16	IN24		

Figure 5-79 The Monitor or the Input ports: IN01-09 iare conducting, IN17 to IN24 no conducting

There are 14 virtual keys we can define the function in Slib-m.nc file. " Slib-m.nc " file can be find in the INSTALL folder for DDCS-Expert.

CONT	READY	Saxis testing.NC	Monitor			2020/01/26 00:41:54	Guest
G54	Mach	Abs	Go Home	Clear All	Go Zero	FRO	100%
X	10.000	0.000	X Home	X Clear	X Go Zero	SRO	100%
Y	10.000	0.000	Y Home	Y Clear	Y Go Zero	SJR	Low 100%
Z	5.000	0.000	Z Home	Z Clear	Z Go Zero	Feed Rate	0 99999
A	20.000	20.000	4th Home	4th Clear	4th Go Zero	Mult S	0-1 24000
C	42.000	42.000	5th Home	5th Clear	5th Go Zero	Cur Tool	T1
EXT KEY			IN			Total No.	7
FUNC K01	FUNC K08		IN01	IN09	IN17	Cur No.	0
FUNC K02	FUNC K09		IN02	IN10	IN18	Cycle Times	0
FUNC K03	FUNC K10		IN03	IN11	IN19	Work Time	00:00:12
FUNC K04	FUNC K11		IN04	IN12	IN20	G49 H 0	
FUNC K05	FUNC K12		IN05	IN13	IN21		
FUNC K06	FUNC K13		IN06	IN14	IN22		
FUNC K07	FUNC K14		IN07	IN15	IN23		
			IN08	IN16	IN24		

## 5.1.9 Coord Set

Then we press F2 key to go to “Coord Set” Page. In the Coord Set Page, we can Select coordinate, and also we can edit the offset between the G54 / G55 / G56 / G57 / G58 / G59 and Mechanical Coordinate.




Figure 5-81 Press F1 key to “Coord Set” Page

In the first Page, there is functions as:Select Coord / Clear X / Clear Z / Z Step / Deeper:





Figure 5-82 First Page of Coord Set

We Press the  Key to go to the second page of Coord Set:

In the second page,there are function as Move Up / Clear 4th / Clear 5th.




Figure 5-83 Second Page of Coor Set

### 5.1.9.1 Select Coord

By the Rotary button(Knob)  or the  and  keys,wen can shift among the different blocks. We select the block,and press Enter or knob,then we can write in numbers.

So we can move our cursor to any Coordinate, and we press “Select Coord”, then the current coordinate is the one we choose.

For example, we move the cursor to any block on G57, and we press “Select Coord” key, then the current Coordinate change from G54 to G57:



Figure 5-84 Current Coordinate is G54



CONT	READY	/udisk-sda1/5axis testing.NC	Monitor	2020/01/26 01:54:27	Guest				
<b>G57</b>	<b>Mach</b>	<b>Abs</b>							
X	-30.052	-30.052							
Y	51.210	51.210							
Z	49.938	48.438							
A	75.470	75.470							
C	320.900	320.900							
	G54	G55	G56	G57	G58	G59	Offset	Total No.	7
X	22.110	0.000	0.000	0.000	0.000	0.000	0.000	Cur No.	0
Y	22.768	0.000	0.000	0.000	0.000	0.000	0.000	Cycle Times	0
Z	18.946	0.000	0.000	0.000	0.000	0.000	1.500	Work Time	00:00:12
A	20.000	0.000	0.000	0.000	0.000	0.000	0.000	G49 H 0	
C	42.000	0.000	0.000	0.000	0.000	0.000	0.000		
1:[Knob]Move the cursor,[Enter]modify.									
2:[Deeper] and [Move Up]Modified Z ext-offse								Z Step	5.00 mm
▲	Move up	Clear 4th	Clear 5th						▶

Figure 5-85 Select the Coordinate to G57

### 5.1.9.2 Clear X / Y / Z / 4th / 5th Axis

When we move the cursor to any block of the coordinate, this coordinate is selected. Then we press “Clear X”, then the X axis value is cleared, and the X axis offset in G57 is created.

CONT	READY	5axis testing.NC	Monitor	2020/01/26 02:24:32	Guest				
<b>G57</b>	<b>Mach</b>	<b>Abs</b>							
X	-30.052	0.000							
Y	50.056	50.056							
Z	57.652	-1.500							
A	75.470	75.470							
C	320.900	320.900							
	G54	G55	G56	G57	G58	G59	Offset	Total No.	7
X	22.110	0.000	0.000	-30.052	0.000	0.000	0.000	Cur No.	0
Y	22.768	0.000	0.000	0.000	0.000	0.000	0.000	Cycle Times	0
Z	18.946	0.000	0.000	57.652	0.000	0.000	1.500	Work Time	00:00:12
A	0.000	0.000	0.000	0.000	0.000	0.000	0.000	G49 H 0	
C	0.000	0.000	0.000	0.000	0.000	0.000	0.000		
1:[Knob]Move the cursor,[Enter]modify.									
2:[Deeper] and [Move Up]Modified Z ext-offse								Z Step	0.50 mm
▲	Select Coord	Clear X	Clear Y	Clear Z	Z Step	Deeper			▶

Figure 5-86 Clear X in Coordinate 57

Here we took X axis for example.

If the users want to clear other axis, just press the according function key.

### 5.1.9.3 Set Z Step

We can set Z step by pressing the “ Z step ” Key (F5). The one step number can be shift among 0.01mm, 0.1mm, 1.00mm, 5.00mm. It’s good both for big distance and small distance setting.

CONT	READY	/udisk-sda1/5axis testing.NC					Monitor	2020/01/26 01:37:25	Guest
<b>G54</b>		<b>Mach</b>			<b>Abs</b>			FRO	100%
⊕ X		-30.052			-52.162			SRO	100%
⊕ Y		51.210			28.442			SJR	Low 100%
⊕ Z		49.938			24.492			Feed Rate	0 99999
⊕ A		75.470			55.470			Mult S	0-1 24000
⊕ C		320.900			278.900			Cur Tool	T1
	G54	G55	G56	G57	G58	G59	Offset	Total No.	7
X	22.110	0.000	0.000	0.000	0.000	0.000	0.000	Cur No.	0
Y	22.768	0.000	0.000	0.000	0.000	0.000	0.000	Cycle Times	0
Z	18.946	0.000	0.000	0.000	0.000	0.000	6.500		
A	20.000	0.000	0.000	0.000	0.000	0.000	0.000		
C	42.000	0.000	0.000	0.000	0.000	0.000	0.000		
1:[Knob]Move the cursor,[Enter]modify.									
2:[Deeper] and [Move Up]Modified Z ext-offse								Z Step	0.01 mm
									00:00:12
								0.10 mm	
								0.50 mm	
								1.00 mm	
								5.00 mm	
▲	Select Coord	Clear X	Clear Y	Clear Z	Z Step	Deeper	▶		

Figure 5-87 Sub-page of CLEAR

### 5.1.9.4 Deeper and Move up

By the “ Deeper ” and “ Move up ” key we can set the Z axis offset very convenient and easily. Each pressing the Z axis offset will change by the value of “ Z step ” Setting.

## 5.1.10 MDI




Figure 5-88 Press F3 key to MDI Page

In the MDI Page, we can edit the G-code ourselves with the controller panel. Here we can edit 6 lines of G-code using the virtual keyboard.







Figure 5-89 MDI Page

By the Rotary button (Knob)  or the  and  keys, we can shift among the different lines. We move the cursor, select a line and Enter, then the Virtual keyboard is active.

There are 3 pages of Virtual keyboard, by the panel Key  we can shift the 3 virtual keyboards.




Figure 5-90 Virtual Keyboard is enabled by "Enter"




Figure 5-91 Edit a line of G-code





Figure 5-92 Edit a line of G-code with another Virtual keyboard



DDCSE Controller Editing-Panel




Figure 5-93 The 3 pages virtual keyboard shifted alternately by pressing Reset Key

As the users finished editing the G-code, press "Execute(1)"--"Execute(6)" (F1--F6) to execute the according G-code line.

## 5.1.11 Middle



Figure 5-94 Press F4 key to Middle Page



Figure 5-95 Middle Page

DDCS-Expert Controller can support two kinds function:

1) Find a middle point for a line: find the Middle point from two points for X or Y axis. And set the middle point as the Zero in the current workpiece coordinate ( G54 - G59 ) ;

2) Find a middle point for the Arc:find the Middle from 3 points. And set the middle point as the Zero in the current workpiece coordinate ( G54 - G59 ) ;

### 5.1.11.1 Find Middle Point in X Axis

In the First Page of Middle, there are 5 functional buttons. Following, we will take example of how to set the Middle to introduce how to use them.




Figure 5-96 Middle Page

Now we set a start point is X = 50, an end point is X = 100. We need to find a Middle from this two point.

Step 1: We move the X axis to X = 50 :



Figure 5-97 X=50

Step 2: Press “ Set X ” ( F1 )

Then the first point is saved.

CONT	READY	5axis testing.NC	Monitor	2020/01/26 22:52:41	Guest	
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%	
X		50.000	50.000	SRO	100%	
Y		0.000	0.000	SJR	Low 100%	
Z		0.000	0.000	Feed Rate	0 99999	
A		0.000	0.000	Mult S	0-1 24000	
C		0.000	0.000	Cur Tool	T1	
4 Pts:				Total No.	7	
	Px1:	50.000	Px2: 0.000	Pxm: 0.000	Cur No.	0
	Py1:	0.000	Py2: 0.000	Pym: 0.000	Cycle Times	0
Manual Center Operation(X):				Work Time	00:00:00	
1: Take the tool to the point Px1 and press [Set X] to set;				G49 H 0		
2: Take the tool to the point Px2 and press [Middle X], get midpoint and set the X zero;						
▲	Set X	Middle X	Set Y	Middle Y	3Pts	

Figure 5-98 First point saved

Step 3: Move the X axis to X = 100 :

CONT	READY	5axis testing.NC	Monitor	2020/01/26 22:52:53	Guest	
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%	
X		100.000	100.000	SRO	100%	
Y		0.000	0.000	SJR	Low 100%	
Z		0.000	0.000	Feed Rate	0 99999	
A		0.000	0.000	Mult S	0-1 24000	
C		0.000	0.000	Cur Tool	T1	
4 Pts:				Total No.	7	
	Px1:	50.000	Px2: 0.000	Pxm: 0.000	Cur No.	0
	Py1:	0.000	Py2: 0.000	Pym: 0.000	Cycle Times	0
Manual Center Operation(X):				Work Time	00:00:00	
1: Take the tool to the point Px1 and press [Set X] to set;				G49 H 0		
2: Take the tool to the point Px2 and press [Middle X], get midpoint and set the X zero;						
▲	Set X	Middle X	Set Y	Middle Y	3Pts	

Figure 5-99 X=100

Step 4: Press the “ Middle X ” key ( F2 ), the system will record the second point, and calculate the Middle point, and set this point position as the Zero.

CONT	READY	5axis testing.NC	Monitor	2020/01/26 22:52:57	Guest	
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%	
X		100.000	25.000	SRO	100%	
Y		0.000	0.000	SJR	Low 100%	
Z		0.000	0.000	Feed Rate	0 99999	
A		0.000	0.000	Mult S	0-1 24000	
C		0.000	0.000	Cur Tool	T1	
4 Pts:				Total No.	7	
	Px1:	50.000	Px2: 100.000	Pxm: 75.000	Cur No.	0
	Py1:	0.000	Py2: 0.000	Pym: 0.000	Cycle Times	0
Manual Center Operation(X):				Work Time	00:00:00	
1: Take the tool to the point Px1 and press [Set X] to set;				G49 H 0		
2: Take the tool to the point Px2 and press [Middle X], get midpoint and set the X zero;						
▲	Set X	Middle X	Set Y	Middle Y	3Pts	

Figure 5-100 Find Middle Point in X Axis



### 5.1.11.2 Find Middle Point in Y Axis

Now we set a start point is Y = 50, an end point is Y=1 00. We need to find a Middle from this two point.

Step 1: We move the Y axis to Y = 50 :

CONT	READY	5axis testing.NC	Monitor	2020/01/26 22:53:13	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕ X		100.000	25.000	SRO	100%
⊕ Y		50.000	50.000	SJR	Low 100%
⊕ Z		0.000	0.000	Feed Rate	0 99999
⊕ A		0.000	0.000	Mult S	0-1 24000
⊕ C		0.000	0.000	Cur Tool	T1
4 Pts:				Total No.	7
Px1: 50.000		Px2: 100.000	Pxm: 75.000	Cur No.	0
Py1: 0.000		Py2: 0.000	Pym: 0.000	Cycle Times	0
Manual Center Operation(X):				Work Time	00:00:00
1: Take the tool to the point Px1 and press [Set X] to set;				G49 H 0	
2: Take the tool to the point Px2 and press [Middle X] get midpoint and set the X zero;					
▲	Set X	Middle X	Set Y	Middle Y	3Pts

Figure 5-101 X=50

Step 2: Press “ Set Y ” ( F3 )

Then the first point is saved.

CONT	READY	5axis testing.NC	Monitor	2020/01/26 22:53:16	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕ X		100.000	25.000	SRO	100%
⊕ Y		50.000	50.000	SJR	Low 100%
⊕ Z		0.000	0.000	Feed Rate	0 99999
⊕ A		0.000	0.000	Mult S	0-1 24000
⊕ C		0.000	0.000	Cur Tool	T1
4 Pts:				Total No.	7
Px1: 50.000		Px2: 100.000	Pxm: 75.000	Cur No.	0
Py1: 50.000		Py2: 0.000	Pym: 0.000	Cycle Times	0
Manual Center Operation(X):				Work Time	00:00:00
1: Take the tool to the point Px1 and press [Set X] to set;				G49 H 0	
2: Take the tool to the point Px2 and press [Middle X] get midpoint and set the X zero;					
▲	Set X	Middle X	Set Y	Middle Y	3Pts

Figure 5-102 First point saved

Step 3: Move the Y axis to Y = 100 :

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 22:53:31	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕ X		100.000	25.000	SRO	100%
⊕ Y		100.000	100.000	SJR	Low 100%
⊕ Z		0.000	0.000	Feed Rate	0 99999
⊕ A		0.000	0.000	Mult S	0-1 24000
⊕ C		0.000	0.000	Cur Tool	T1
4 Pts:				Total No.	7
Px1:	50.000	Px2:	100.000	Pxm:	75.000
Py1:	50.000	Py2:	0.000	Py2:	0.000
Manual Center Operation(X):				Cur No.	0
1: Take the tool to the point Px1 and press [Set X] to set;				Cycle Times	0
2: Take the tool to the point Px2 and press [Middle X], get midpoint and set the X zero;				Work Time	00:00:00
				G49 H 0	
▲	Set X	Middle X	Set Y	Middle Y	3Pts

Figure 5-103 Y=100

Step 4: Press the “ Middle Y ” key ( F4 ), the system will record the second point, and calculate the Middle point, and set this middle point position as the Zero.

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 22:53:35	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕ X		100.000	25.000	SRO	100%
⊕ Y		100.000	25.000	SJR	Low 100%
⊕ Z		0.000	0.000	Feed Rate	0 99999
⊕ A		0.000	0.000	Mult S	0-1 24000
⊕ C		0.000	0.000	Cur Tool	T1
4 Pts:				Total No.	7
Px1:	50.000	Px2:	100.000	Pxm:	75.000
Py1:	50.000	Py2:	100.000	Py2:	75.000
Manual Center Operation(X):				Cur No.	0
1: Take the tool to the point Px1 and press [Set X] to set;				Cycle Times	0
2: Take the tool to the point Px2 and press [Middle X], get midpoint and set the X zero;				Work Time	00:00:00
				G49 H 0	
▲	Set X	Middle X	Set Y	Middle Y	3Pts

Figure 5-104 Find Middle point in Y axis

4 Pts:					
Px1:	50.000	Px2:	100.000	Pxm:	75.000
Py1:	50.000	Py2:	100.000	Pym:	75.000

Px1 = First point Position in X Axis in Mechanical Coordinate;

Py1 = First point Position in Y Axis in Mechanical Coordinate;

Px2 = The second point Position in X Axis in Mechanical Coordinate;

Py2 = The second point Position in Y Axis in Mechanical Coordinate;

Pxm = The Middle Point Position in X Axis in Mechanical Coordinate;

Pym = The Middle Point Position in Y Axis in Mechanical Coordinate.

### 5.1.11.3 Find a middle point for the Arc




Figure 5-105 Press F6 Go to Middle Arc Page



Figure 5-106 Middle Arc Page

Here we also take an example to introduce the function.

To find a middle point for an Arc, we need to set 3 points on the Arc. Lets say, the first point is  $X = 50 / Y = 100$ , the second point is  $X = 100 / Y = 50$ , the third point is  $X = 50 / Y = 0$ .

Step 1: Set the first Point Position: We move the machine to  $X = 50 / Y = 100$ :

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 23:01:15	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
X	50.000	50.000	SRO	100%	
Y	100.000	100.000	SJR	Low 100%	
Z	0.000	0.000	Feed Rate	0 99999	
A	0.000	0.000	Mult S	0-1 24000	
C	0.000	0.000	Cur Tool	T1	
Arc 3 pts			Total No.	7	
First pts:	Second pts:	Third pts:	Center:	Cur No.	0
X: 0.000	0.000	0.000	0.000	Cycle Times	0
Y: 0.000	0.000	0.000	0.000	Work Time	00:00:00
1: Move to the first point and press [Set 1]; 2: Move to the second point and press [Set 2]; 3: Move to the third point and press [Middle], get center of arc and set it to zero;					
▲	Set 1	Set 2	Middle		4pts

Figure 5-107 X=50,Y=100

Step 2: Press “Set 1” Key ( F1 ), then the first point Position is saved.

MPG	READY	23232.txt	IO	2000/12/22 05:13:49	Guest								
Stat	Port Name				Enable	Pin No.	Polarity						
●	X-axis servo alarm signal				x	NULL	N						
●	Y-axis servo alarm signal				x	NULL	N						
●	Z-axis servo alarm signal				x	NULL	N						
●	Spindle alarm signal				x	NULL	N						
●	5th-axis servo alarm signal				x	NULL	N						
●	negative X-axis hard limit signal				x	NULL	N						
●	negative Y-axis hard limit signal				x	NULL	N						
●	negative Z-axis hard limit signal				x	NULL	N						
●	negative 4th-axis hard limit signal				x	NULL	N						
●	negative 5th-axis hard limit signal				x	NULL	N						
●	positive X-axis hard limit signal				x	NULL	N						
●	positive Y-axis hard limit signal				x	NULL	N						
IN	IN01	IN02	IN03	IN04	IN05	IN06	IN07	IN08	IN09	IN10	IN11	IN12	IN13
	IN14	IN15	IN16	IN17	IN18	IN19	IN20	IN21	IN22	IN23	IN24		
MPG	X1	X10	X100	HX	HY	H2	HA	HB		-54			0
OUT	OUT01	OUT02	OUT03	OUT04	OUT05	OUT06	OUT07	OUT08	OUT09	OUT10	OUT11	OUT12	OUT13
	OUT14	OUT15	OUT16	OUT17	OUT18	OUT19	OUT20	OUT21					
▲	Out Open		Out Close		Change Polarity								

Figure 5-108 First point Position is saved

Step 3: Set the second Point Position: We move the machine to X = 100 / Y = 50:

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 23:01:32	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
X	100.000	100.000	SRO	100%	
Y	50.000	50.000	SJR	Low 100%	
Z	0.000	0.000	Feed Rate	0 99999	
A	0.000	0.000	Mult S	0-1 24000	
C	0.000	0.000	Cur Tool	T1	
Arc 3 pts			Total No.	7	
First pts:	Second pts:	Third pts:	Center:	Cur No.	0
X: 50.000	0.000	0.000	0.000	Cycle Times	0
Y: 100.000	0.000	0.000	0.000	Work Time	00:00:00
1: Move to the first point and press [Set 1]; 2: Move to the second point and press [Set 2]; 3: Move to the third point and press [Middle], get center of arc and set it to zero;					
▲	Set 1	Set 2	Middle		4pts

Figure 5-109 X=100,Y=50

Step 4: Press “Set 2” Key ( F2 ), then the second point Position is saved.

CONT	READY	Saxis testing.NC	Monitor	2020/01/27 00:23:55	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
X		100.000	100.000	SRO	100%
Y		50.000	50.000	SJR	Low 100%
Z		0.000	0.000	Feed Rate	0 99999
A		0.000	0.000	Mult S	0-1 24000
C		0.000	0.000	Cur Tool	T1
Arc 3 pts:				Total No.	7
	First pts:	Second pts:	Third pts:	Center:	Cur No.
	X: 50.000	100.000	0.000	0.000	0
	Y: 100.000	50.000	0.000	0.000	Cycle Times
	1: Move to the first point and press [Set 1];				0
	2: Move to the second point and press [Set 2];				Work Time
	3: Move to the third point and press [Middle], get center of arc and set it to zero;				00:00:00
				G49 H 0	
▲	Set 1	Set 2	Middle		4pts

Figure 5-110 The second point Position is saved

Step 5: Set the third Point Position: We move the machine to X = 50 / Y = 0 :

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 23:01:47	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
X		50.000	50.000	SRO	100%
Y		0.000	0.000	SJR	Low 100%
Z		0.000	0.000	Feed Rate	0 99999
A		0.000	0.000	Mult S	0-1 24000
C		0.000	0.000	Cur Tool	T1
Arc 3 pts:				Total No.	7
	First pts:	Second pts:	Third pts:	Center:	Cur No.
	X: 50.000	100.000	0.000	0.000	0
	Y: 100.000	50.000	0.000	0.000	Cycle Times
	1: Move to the first point and press [Set 1];				0
	2: Move to the second point and press [Set 2];				Work Time
	3: Move to the third point and press [Middle], get center of arc and set it to zero;				00:00:00
				G49 H 0	
▲	Set 1	Set 2	Middle		4pts

Figure 5-111 X=50,Y=0

Step 6: Press “ Middle ” Key ( F3 ), then the third point Position is saved. And The system calculate the Middle point from the 3 point position, and set this middle point position as the Zero in the workpiece coordinate ( G54 - G59 ) .

CONT	READY	Saxis testing.NC	Monitor	2020/01/26 23:01:54	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
X		50.000	0.000	SRO	100%
Y		0.000	-50.000	SJR	Low 100%
Z		0.000	0.000	Feed Rate	0 99999
A		0.000	0.000	Mult S	0-1 24000
C		0.000	0.000	Cur Tool	T1
Arc 3 pts:				Total No.	7
	First pts:	Second pts:	Third pts:	Center:	Cur No.
	X: 50.000	100.000	50.000	50.000	0
	Y: 100.000	50.000	0.000	50.000	Cycle Times
	1: Move to the first point and press [Set 1];				0
	2: Move to the second point and press [Set 2];				Work Time
	3: Move to the third point and press [Middle], get center of arc and set it to zero;				00:00:00
				G49 H 0	
▲	Set 1	Set 2	Middle		4pts

Figure 5-112 Find Middle for the Arc

Arc 3 pts:				
	First pts:	Second pts:	Third pts:	Center:
X:	50.000	100.000	50.000	50.000
Y:	100.000	50.000	0.000	50.000

First Pts:

X: The First Point Position in X axis in Mechanical Coordinate;

Y: The First Point Position in X axis in Mechanical Coordinate;

Second Pts:

X: The second point Position in X Axis in Mechanical Coordinate;

Y: The second point Position in Y Axis in Mechanical Coordinate;

Third Pts:

X: The Third point Position in X Axis in Mechanical Coordinate;

Y: The Third point Position in Y Axis in Mechanical Coordinate;

Center Pts:

X: The Center Points in X Axis in Mechanical Coordinate;

Y: The Center Points in X Axis in Mechanical Coordinate.

www.ddcnc.com

## 5.1.12 Work Record




Figure 5-113 Press F5 key to "Work Record" Page

In the Work Record Page, we can check out the work record after the controller power on.




Figure 5-114 "Work Record" Page

No.: The Processed G-code file Number;

Name: The G-code file name;

Total Time: The according G-code file processing time;

No.: The processing times of the according G-code file;

Start date: The G-code file start processing time;

Current File: The current G-code file,if you press G-code file, system will process the current file.

Press F2, the system will export the working record to USB stick and named it as “ PROCESS\_MSG.txt ”.




Figure 5-115 Save the record to U Disk

Press F1,The System clear all the record.



Figure 5-116 Clear the working record



## 5.1.13 Sort Process

“Sort Process” function is in reservation now.




Figure 5-117 Press F6 key to “Sort Process” Page




Figure 5-118 Press F6 key to “Sort Process” Page

In the Sort Process Page, we can organize, sort, and set times and sequence of different G-code files in our control system.

Press “New” Key ( F3 ) to import some G-code file from the Local Disk. Please note that the files can only be imported from the Local Disk. If you have the files in USB-stick, please copy them into the local disk firstly.

CONT	READY	/udisk-sda1/test.nc	Program	2020/01/27 05:08:49	Guest
Local Disk(C)		Name	Size	Modify time	
U Disk(N)		2mmnewM47.tap	879 B	2020/01/27 13:05	
Net Disk(G)		ball1.nc	1.58 M	2020/01/27 13:05	
		2mmnewG41N.tap	80 B	2020/01/27 13:05	
		NEWBALL.nc	2.37 M	2020/01/27 13:05	
		2mmnew.tap	1.45 M	2020/01/27 13:05	
Cur Path:		/local	Free Space:	824.77 MB	
▲	Switch disks	Del	Rename	Copy To U Disk	New Edit ▶

Figure 5-119 Import the G-code files from the Local Disk

CONT	READY	/udisk-sda1/test.nc	Monitor	2020/01/27 05:09:14	Guest
<b>G54</b>		<b>Mach</b>	<b>Abs</b>	FRO	100%
⊕	X	10.000	0.000	SRO	100%
⊕	Y	10.000	0.000	SJR	Low 100%
⊕	Z	5.000	0.000	Feed Rate	0 99999
⊕	A	0.000	0.000	Mult S	0-1 24000
⊕	C	0.000	0.000	Cur Tool	T1
No.	Status	Times	Name(local)	(G54/G55)	Total No.
1	READY	0/1	/local/ball1.nc	G54	7
2	READY	0/1	/local/2mmnewM47.tap	G54	Cur No.
3	READY	0/1	/local/2mmnewG41N.tap	G54	0
4	READY	0/1	/local/NEWBALL.nc	G54	Cycle Times
5	READY	0/1	/local/2mmnew.tap	G54	0
					Work Time
					00:00:00
					G49 H 0
▲	Up	Down	New	Del	Times Load List ▶

Figure 5-120 The G-code files imported in

[www.nvcnc.net](http://www.nvcnc.net)